


### PB Inside Diameter Air Probe

**PB Inside Diameter Air Probe** Mainly used for through hole measurements, the PB is a non-contact style sensor which shoots air through its orifices against a work object. The nozzle is at 3 to 4 mm from the tip of the probe.



#### Sensor Probe Dimensions

Size D	B	C	E	F	G	Chart
2 to 2.5 mm	4	15	12	13.9	90	1
2.5 to 4 mm	4	25	12	13.9	90	
4 to 8 mm	3	20	12	13.9	90	2
8 to 11.5 mm	4	20	12	13.9	90	3
11.5 to 14 mm	4	45	12	13.9	90	4
14 to 24 mm	4	45	14	16.2	90	
24 to 40 mm	4	45	17	19.6	90	
40 to 50 mm	4	50	21	24.3	110	
50 to 65 mm	4	50	21	24.3	110	
65 to 100	4	50	26	30.0	110	